



ТОЧИЛКА ДЛЯ НОЖЕЙ ЭЛЕКТРИЧЕСКАЯ HURAKAN HKN-KNS4

Поз	Наименование детали
1	Front cover
2	Seat
3	Switch off
4	Host
5	Fine weel
6	Rent weel
7	Back cover
8	Fixed frame
9	Power cord